


THE ASPEN

ROUND TAPER LEG



1010 ASPEN

1:150 SCALE SHOWN

101022 LEFT ARM LOVESEAT
101031 RIGHT ARM CORNER SOFA

	TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG
101009	CORNER CHAIR	101011	RIGHT ARM CHAIR	101012	LEFT ARM CHAIR	101013	ARMLESS CHAIR	101020	LOVESEAT	101021	R ARM LOVESEAT
TOTAL	W37" D37" H33"	TOTAL	W31" D37" H33"	TOTAL	W31" D37" H33"	TOTAL	W26" D37" H33"	TOTAL	W62" D37" H33"	TOTAL	W57" D37" H33"
SEAT	W22" D22" H20"	SEAT	W26" D22" H20"	SEAT	W26" D22" H20"	SEAT	W26" D22" H20"	SEAT	W52" D22" H20"	SEAT	W52" D22" H20"
ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---

	TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG
101022	L ARM LOVESEAT	101030	SOFA	101031	R ARM CORNER SOFA	101032	L ARM CORNER SOFA	101033	RIGHT ARM SOFA	101034	LEFT ARM SOFA
TOTAL	W57" D37" H33"	TOTAL	W88" D37" H33"	TOTAL	W94" D37" H33"	TOTAL	W94" D37" H33"	TOTAL	W83" D37" H33"	TOTAL	W83" D37" H33"
SEAT	W52" D22" H20"	SEAT	W78" D22" H20"	SEAT	W79" D22" H20"	SEAT	W79" D22" H20"	SEAT	W78" D22" H20"	SEAT	W78" D22" H20"
ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---

	TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG
101035	APARTMENT SOFA	101036	R ARM APT SOFA	101037	L ARM APT SOFA	101060	CHAISE	101061	RIGHT ARM CHAISE	101062	LEFT ARM CHAISE
TOTAL	W78" D37" H33"	TOTAL	W73" D37" H33"	TOTAL	W73" D37" H33"	TOTAL	W39" D63" H33"	TOTAL	W35" D63" H33"	TOTAL	W35" D63" H33"
SEAT	W68" D22" H20"	SEAT	W68" D22" H20"	SEAT	W68" D22" H20"	SEAT	W30" D48" H20"	SEAT	W30" D48" H20"	SEAT	W30" D48" H20"
ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---

	TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG
101063	ARMLESS CHAISE	101071	RIGHT ARM BUMPER	101072	LEFT ARM BUMPER	101080	LONG SOFA	101081	R ARM LONG SOFA	101082	L ARM LONG SOFA
TOTAL	W30" D63" H33"	TOTAL	W37" D85" H33"	TOTAL	W37" D85" H33"	TOTAL	W98" D37" H33"	TOTAL	W93" D37" H33"	TOTAL	W93" D37" H33"
SEAT	W30" D48" H20"	SEAT	W30" D70" H20"	SEAT	W30" D70" H20"	SEAT	W88" D22" H20"	SEAT	W88" D22" H20"	SEAT	W88" D22" H20"
ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---



N.C. MADE



CONFIGURATIONS		WIDTH	DEPTH	HEIGHT
101009	ASPEN CORNER CHAIR ROUND TAPER LEG	37in.	37in.	33in.
101011	ASPEN RIGHT ARM CHAIR ROUND TAPER LEG	31in.	37in.	33in.
101012	ASPEN LEFT ARM CHAIR ROUND TAPER LEG	31in.	37in.	33in.
101013	ASPEN ARMLESS CHAIR ROUND TAPER LEG	26in.	37in.	33in.
101020	ASPEN LOVESEAT ROUND TAPER LEG	62in.	37in.	33in.
101021	ASPEN RIGHT ARM LOVESEAT ROUND TAPER LEG	57in.	37in.	33in.
101022	ASPEN LEFT ARM LOVESEAT ROUND TAPER LEG	57in.	37in.	33in.
101030	ASPEN SOFA ROUND TAPER LEG	88in.	37in.	33in.
101031	ASPEN RIGHT ARM CORNER SOFA ROUND TAPER LEG	94in.	37in.	33in.
101032	ASPEN LEFT ARM CORNER SOFA ROUND TAPER LEG	94in.	37in.	33in.
101033	ASPEN RIGHT ARM SOFA ROUND TAPER LEG	83in.	37in.	33in.
101034	ASPEN LEFT ARM SOFA ROUND TAPER LEG	83in.	37in.	33in.
101035	ASPEN APARTMENT SOFA ROUND TAPER LEG	78in.	37in.	33in.
101036	ASPEN RIGHT ARM APARTMENT SOFA ROUND TAPER LEG	73in.	37in.	33in.
101037	ASPEN LEFT ARM APARTMENT SOFA ROUND TAPER LEG	73in.	37in.	33in.
101060	ASPEN CHAISE ROUND TAPER LEG	39in.	63in.	33in.
101061	ASPEN RIGHT ARM CHAISE ROUND TAPER LEG	35in.	63in.	33in.
101062	ASPEN LEFT ARM CHAISE ROUND TAPER LEG	35in.	63in.	33in.
101063	ASPEN ARMLESS CHAISE ROUND TAPER LEG	30in.	63in.	33in.
101071	ASPEN RIGHT ARM BUMPER ROUND TAPER LEG	37in.	85in.	33in.
101072	ASPEN LEFT ARM BUMPER ROUND TAPER LEG	37in.	85in.	33in.
101080	ASPEN LONG SOFA ROUND TAPER LEG	98in.	37in.	33in.
101081	ASPEN RIGHT ARM LONG SOFA ROUND TAPER LEG	93in.	37in.	33in.
101082	ASPEN LEFT ARM LONG SOFA ROUND TAPER LEG	93in.	37in.	33in.



THE ASPEN

N.C. MADE




HAND-BUILT FURNITURE

CONFIGURATIONS

		WIDTH	DEPTH	HEIGHT
101109	ASPEN CORNER CHAIR BUBBLE LEG	37 in.	37 in.	33 in.
101111	ASPEN RIGHT ARM CHAIR BUBBLE LEG	31 in.	37 in.	33 in.
101112	ASPEN LEFT ARM CHAIR BUBBLE LEG	31 in.	37 in.	33 in.
101113	ASPEN ARMLESS CHAIR BUBBLE LEG	26 in.	37 in.	33 in.
101120	ASPEN LOVESEAT BUBBLE LEG	62 in.	37 in.	33 in.
101121	ASPEN RIGHT ARM LOVESEAT BUBBLE LEG	57 in.	37 in.	33 in.
101122	ASPEN LEFT ARM LOVESEAT BUBBLE LEG	57 in.	37 in.	33 in.
101130	ASPEN SOFA BUBBLE LEG	88 in.	37 in.	33 in.
101131	ASPEN RIGHT ARM CORNER SOFA BUBBLE LEG	94 in.	37 in.	33 in.
101132	ASPEN LEFT ARM CORNER SOFA BUBBLE LEG	94 in.	37 in.	33 in.
101133	ASPEN RIGHT ARM SOFA BUBBLE LEG	83 in.	37 in.	33 in.
101134	ASPEN LEFT ARM SOFA BUBBLE LEG	83 in.	37 in.	33 in.
101135	ASPEN APARTMENT SOFA BUBBLE LEG	78 in.	37 in.	33 in.
101136	ASPEN RIGHT ARM APARTMENT SOFA BUBBLE LEG	73 in.	37 in.	33 in.
101137	ASPEN LEFT ARM APARTMENT SOFA BUBBLE LEG	73 in.	37 in.	33 in.
101160	ASPEN CHAISE BUBBLE LEG	39 in.	63 in.	33 in.
101161	ASPEN RIGHT ARM CHAISE BUBBLE LEG	35 in.	63 in.	33 in.
101162	ASPEN LEFT ARM CHAISE BUBBLE LEG	35 in.	63 in.	33 in.
101163	ASPEN ARMLESS CHAISE BUBBLE LEG	30 in.	63 in.	33 in.
101171	ASPEN RIGHT ARM BUMPER BUBBLE LEG	37 in.	85 in.	33 in.
101172	ASPEN LEFT ARM BUMPER BUBBLE LEG	37 in.	85 in.	33 in.
101180	ASPEN LONG SOFA BUBBLE LEG	98 in.	37 in.	33 in.
101181	ASPEN RIGHT ARM LONG SOFA BUBBLE LEG	93 in.	37 in.	33 in.
101182	ASPEN LEFT ARM LONG SOFA BUBBLE LEG	93 in.	37 in.	33 in.

THE ASPEN

BUBBLE LEG



1011 ASPEN

1:150 SCALE SHOWN

101122
101131

LEFT ARM LOVESEAT
RIGHT ARM CORNER SOFA

	TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG
101109	CORNER CHAIR	101111	RIGHT ARM CHAIR	101112	LEFT ARM CHAIR	101113	ARMLESS CHAIR	101120	LOVESEAT	101121	R ARM LOVESEAT
TOTAL	W37" D37" H33"	TOTAL	W31" D37" H33"	TOTAL	W31" D37" H33"	TOTAL	W26" D37" H33"	TOTAL	W62" D37" H33"	TOTAL	W57" D37" H33"
SEAT	W22" D22" H20"	SEAT	W26" D22" H20"	SEAT	W26" D22" H20"	SEAT	W26" D22" H20"	SEAT	W52" D22" H20"	SEAT	W52" D22" H20"
ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---

	TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG
101122	L ARM LOVESEAT	101130	SOFA	101131	R ARM CORNER SOFA	101132	L ARM CORNER SOFA	101133	RIGHT ARM SOFA	101134	LEFT ARM SOFA
TOTAL	W57" D37" H33"	TOTAL	W88" D37" H33"	TOTAL	W94" D37" H33"	TOTAL	W94" D37" H33"	TOTAL	W83" D37" H33"	TOTAL	W83" D37" H33"
SEAT	W52" D22" H20"	SEAT	W78" D22" H20"	SEAT	W79" D22" H20"	SEAT	W79" D22" H20"	SEAT	W78" D22" H20"	SEAT	W78" D22" H20"
ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---

	TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG
101135	APARTMENT SOFA	101136	R ARM APT SOFA	101137	L ARM APT SOFA	101160	CHAISE	101161	RIGHT ARM CHAISE	101162	LEFT ARM CHAISE
TOTAL	W78" D37" H33"	TOTAL	W73" D37" H33"	TOTAL	W73" D37" H33"	TOTAL	W39" D63" H33"	TOTAL	W35" D63" H33"	TOTAL	W35" D63" H33"
SEAT	W68" D22" H20"	SEAT	W68" D22" H20"	SEAT	W68" D22" H20"	SEAT	W30" D48" H20"	SEAT	W30" D48" H20"	SEAT	W30" D48" H20"
ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---

	TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG		TAPER LEG
101163	ARMLESS CHAISE	101171	RIGHT ARM BUMPER	101172	LEFT ARM BUMPER	101180	LONG SOFA	101181	R ARM LONG SOFA	101182	L ARM LONG SOFA
TOTAL	W30" D63" H33"	TOTAL	W37" D85" H33"	TOTAL	W37" D85" H33"	TOTAL	W98" D37" H33"	TOTAL	W93" D37" H33"	TOTAL	W93" D37" H33"
SEAT	W30" D48" H20"	SEAT	W30" D70" H20"	SEAT	W30" D70" H20"	SEAT	W88" D22" H20"	SEAT	W88" D22" H20"	SEAT	W88" D22" H20"
ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---	ARMS	---